

SHIMANO

CALCUTTA CONQUEST SA-RB




CTCQ-200

[CLICK HERE](#) For Bearing Kits in Stainless Steel and Ceramic

OR

Click on the circled bearings to see options for each



LEGEND

- Factory Ball Bearings
- 1-Way Roller Clutch Bearing

This reel has no bushes that can be upgraded

Please note that the number of adjusting washers may not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

(51RH820200U)

Part No.	Description	Part No.	Description	Part No.	Description
BNT0015	Drag Spring Washer	BNT4933	Handle Nut Plate	BNT5019	Bearing Spacer
BNT0032	Bearing Retainer	BNT4934	Handle Knob Seal	BNT5020	Set Plate Sticker
BNT0623	Screw	BNT4935	Handle Knob	BNT5021	Roller Clutch Bearing
BNT0664	Spacer B	BNT4938	Click Pin	BNT5022	Right Side Plate
BNT0987	Screw	BNT4939	Click Spring	BNT5023	Drag Washer
BNT1465	Clutch Pawl Spring	BNT4940	Star Drag	BNT5024	Drive Gear
BNT1652	Screw	BNT4941	Cast Control Cap	BNT5025	Anti-Reverse Ratchet
BNT1672	E Lock	BNT4942	Cast Control Click Holder	BNT5026	Drive Shaft
BNT1696	Cast Control Spacer	BNT4943	Cast Control Cap Assembly	BNT5027	Idle Gear Spring
BNT2117	Handle Nut	BNT4944	Ball Bearing	BNT5028	Drive Shaft Retainer
BNT2120	Click Plate Retainer	BNT4945	Ball Bearing	BNT5029	Frame Shield
BNT2121	Star Drag Click	BNT4954	Idle Gear	BNT5030	Stabilizer Bar
BNT2127	Star Drag Spacer	BNT4956	Screw	BNT5031	Worm Shaft
BNT2128	Bearing Washer	BNT4958	Idle Gear	BNT5032	Level Wind Guard
BNT2158	Screw	BNT4959	Washer	BNT5033	Pinion Gear
BNT2819	Washer	BNT4960	Ball Bearing	BNT5034	Yoke Spring
BNT3060	Screw	BNT4964	Yoke	BNT5035	Clutch Plate
BNT3068	Screw	BNT4965	Clutch Cam Retainer	BNT5036	Clutch Guard
BNT3076	O Ring	BNT4966	Clutch Cam	BNT5037	One-Piece Frame
BNT3814	Key Washer	BNT4969	Line Guide	BNT5038	Clutch Bar Guide
BNT3915	Drag Washer	BNT4970	Line Guide Pawl	BNT5039	Clutch Lever
BNT3927	Ball Bearing	BNT4971	Washer	BNT5040	Spool Assembly
BNT4014	Screw	BNT4972	Pawl Cap	BNT5041	Brake Case
BNT4116	Screw	BNT4973	Screw	BNT5042	Brake Case Cam
BNT4187	Ball Bearing	BNT4979	Brake Shoe M	BNT5043	Side Plate Cam Lever
BNT4431	Washer	BNT4980	Brake Pipe Gear	BNT5044	B Side Plate Insert
BNT4631	Idle Gear Pin	BNT4981	O Ring	BNT5045	Damper Bush(A)
BNT4638	Clutch Pawl	BNT4982	Screw	BNT5046	Damper Spring
BNT4695	Handle Knob Pipe	BNT4983	Br Dial Gear	BNT5047	B Side Plate Seal
BNT4699	Star Drag Spring	BNT4984	O Ring	BNT5048	Left Side Plate
BNT4700	Star Drag Nut	BNT4986	Washer		
BNT4704	Cast Control Click Plate	BNT4991	Washer		
BNT4710	Roller Clutch Inner Tube	BNT4992	Br Dial		
BNT4720	Clutch Pawl Bushing	BNT5017	Handle Shank Assembly		
BNT4742	Washer	BNT5018	Handle Assembly		
				BNT4692	B-100 Oil (accessory)