

SHIMANO

STRADIC SA-RB



STRADIC1000HGL


LEGEND

- Factory Ball Bearings
- Bushes that can be Upgraded to Ball Bearings

[CLICK HERE](#) For Bearing Kits in Stainless Steel and Ceramic

OR

Click on the circled bearings to see options for each bearing



Please note that the number of adjusting washers may not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

(51SF27B012X)

Part No.	Description	Part No.	Description	Part No.	Description
RD 0647	Screw	RD18724	Spring Guide A Support	RD19990	Screw
RD 7418	Screw	RD18725	Bail Spring Guide A	RD19992	Worm Bushing (Front)
RD 8916	Click Spring	RD18732	Rotor Ring	RD19993	Worm Shaft Retainer
RD 9833	Ratchet Spring	RD18735	Roller Clutch Assembly	RD19994	Washer
RD10415	Drag Washers Retainer	RD18741	Washer	RD19997	Washer
RD10906	Ball Bearing	RD18744	Idle Gear	RD19998	Ball Bearing
RD12969	Ball Bearing	RD18758	Washer	RD20129	Drag Knob Assembly
RD13269	Ball Bearing	RD18785	Handle Knob Assembly	RD20132	Bail Assembly
RD14780	Screw	RD18905	Idle Gear S	RD20133	Main Shaft Assembly
RD14861	Key Washer	RD19136	Line Roller Spacer	RD20139	O Ring
RD14867	Spool Support	RD19775	Screw	RD20144	Rotor
RD16122	Spool Bushing	RD19776	Screw	RD20146	Bail Arm
RD16801	Washer	RD19777	Screw	RD20147	Bail Spring Cover
RD17177	Screw	RD19780	O Ring	RD20148	Bail Hold Support Guard
RD17183	Drag Click Spring	RD19781	O Ring	RD20149	Counter Weight
RD17184	Drag Click	RD19790	Rotor Nut	RD20150	Line Roller Collar
RD17197	Screw	RD19793	Bearing Water Proof	RD20152	Rotor Brim
RD17220	Screw	RD19802	Bail Trip Strike	RD20153	Body
RD17326	Bail Spring	RD19805	Main Shaft Collar	RD20156	Handle Screw Cap
RD17374	Screw	RD19806	Washer	RD20157	Oscillating Guide A
RD17415	Click Pin	RD19807	Oscillating Pawl	RD20158	Worm Shaft
RD17666	Spool Washer	RD19818	Oscillating Pawl Cover	RD20165	Idle Gear B Shaft
RD17667	Set Screw	RD19822	Bearing Retainer	RD20166	Rear Protector
RD17681	Line Roller Support	RD19831	O Ring	RD20168	Washer
RD17684	Bail Spring Guide B	RD19837	Line Roller Bushing	RD20170	Washer
RD17685	Bail Spring Guide A Bush	RD19856	Bail Trip Lever	RD20171	Handle Shaft Cover B
RD17695	Handle Shaft Seal	RD19866	O Ring	RD20173	Washer
RD17698	Handle Knob Bushing	RD19883	Friction Ring	RD20174	Washer
RD17700	Screw	RD19884	Oscillating Slider Bushing	RD20177	Spool Assembly
RD17701	Handle Knob Seal	RD19886	Flange Water Proof	RD20178	Handle Shank Assembly
RD17773	Drag Washer	RD19899	Roller Clutch Inner	RD20179	Handle Assembly
RD18206	Bearing Bushing	RD19926	Rotor Nut Lock Plate	RD20181	Pinion Gear
RD18207	Drag Click Ratchet	RD19959	Line Roller	RD20183	Side Cover Assembly
RD18208	Spacer	RD19976	Worm Bushing (Rear)	RD20186	Idle Gear L
RD18503	Washer	RD19989	Screw	RD20189	Drive Gear